



Unit:mm



Input indicator light

Current adjusting knob

Voltage adjusting knob

1

2

3

4

5

6

7

8

9

10

FG

AC-L

AC-N

NC

Vout+

NC

Vout-

NC

Sense +

Sense -